

Ethanol fireplace ROLL FIRE

Product contents

- 1 steel body, black powder-coated (1 outer cover with ball bearing-mounted interior lining)
- 1 ethanol tank with grate (stainless steel + heat-resistant, black-coated steel)
- 1 glass pane with black printing – with central hole
- 1 glass pane with black printing – without central hole
- 1 funnel for filling the ethanol tank
- 1 poker to operate the tank control
- 1 suede glove
- 1 protective jacket (black, heat-resistant needle felt with Velcro fastening)
- 1 bottle of bioethanol (contents: 1 litre)
- Optional: wall bracket

Assembly

1. Set up the steel body and insert the tank.
2. The protective jacket made of black needle felt provided can optionally be laid around the Roll Fire and fastened with the Velcro fastening before the flame is ignited. It protects the sliding surface against scratches and insulates the fireplace's heated steel surface.
3. Attach the rear glass pane (without central hole). For this, allow the magnets on the glass pane to latch onto the magnet holders on the fireplace body.
4. Open the tank and the fuel supply opening.
5. With the help of the funnel, fill the tank with 2 litres of bioethanol via the fuel supply opening in front of the grate.
6. The bioethanol may now be directly ignited in the tank using a BBQ lighter or fireplace matches.
7. Leave the fuel supply opening open during use – this prevents gas from building up underneath the tank cover plate which could cause an explosion.
8. Place the glass pane (with central hole) in front of it. (see point 2)

Note: The central hole in the glass pane enables the tank opening to be adjusted, opened or closed using the poker provided, without having to remove the glass pane.

Please ensure you read the following notes before starting up the fireplace:

Precautions

- The fireplace may only be rolled slowly and carefully when it is lit. For this, always use the suede glove provided, as the surfaces and the glass panes will become hot – risk of burns!
- The fuel may only be used in the fuel container provided for it.
- Only fill the tank through the fuel supply opening.
- The tank may only be operated with no more than 2 litres of fuel.
- Please note that the fireplace may only be operated under supervision and by qualified persons.
- Avoid moving about too close to the unit. People should keep a safe distance of 0.5 m from the lit fireplace.
- Keep children away from hot surfaces/glass panes.
- Ensure that you keep an adequate distance from inflammable objects and materials.
- Do not smoke when you fill the fireplace.
- Do not place any objects on the flames.
- Always use a BBQ lighter or a long fireplace match to light the fire. Ignite the fireplace with an outstretched arm and standing to one side.
- No modifications may be made to the construction of the fireplace.

Operation

Before you add more fuel, the fireplace, all surfaces and panes must be completely cool. **Never top up by pouring fuel into the fireplace while it is burning or when the tank is still hot. Risk of burns!** Stand to one side to fill the tank and make sure that you stand as far away as possible from the fireplace. Please ensure that you do not spill any fuel that could ignite over a large area when you light the unit.

Ethanol fireplace ROLL FIRE

The technically sophisticated and high-quality fuel tank is protected against fuel spillage with several double-walled chambers and so-called breakwaters using inserted plates. It also has a double-coated tank cover, which falls shut whenever the tank is moved too vigorously. Despite these various safety measures, which allow the fireplace to be moved even when it is lit, **ROLL FIRE may only be rolled slowly and carefully.**

Movements that are too strong and jerky, as well as tipping to the side, could exceed the limits of the tank's safety function.

Cleaning and care

Always allow the fireplace to burn itself out if possible and then leave it to cool. Bioethanol burns without leaving any residues. Wipe the cooled surfaces with a soft microfibre cloth and warm water. Do not use any aggressive cleaning products.

Bioethanol

The fireplace is only suitable for liquid bioethanol. The use of combustion gel would lead to the build-up of dirt and would compromise the function and the combustion behaviour.

Use a high-quality fuel. This will burn with a lovely yellow and red flame, create no odours and will burn for longer than cheaper fuels which often also contain toxic additives. Trials with a very wide range of fuels have resulted in our only being able to provide a warranty for the quality, safety and function of our products with Conmoto bioethanol. You can order Conmoto bioethanol from us in cartons of 12 (1 bottle = 1 litre) at any time. We will send you precise details of the contents of these products and the safety data sheet on request.

During the combustion process, ensure that there is an occasional supply of fresh air, for example through an open window, since the fire will take around the same volume of oxygen from the ambient air as two to three medium-sized candles. Draughts should generally be avoided, as these can cause soot formation and an irregular flame form.

The following applies for bioethanol: Highly flammable. Avoid inhaling the vapours. Avoid direct contact with skin and eyes. Danger of burning from spilt fuel. Do not smoke when handling the fuel. Keep container tightly closed. Keep away from ignition sources. Keep away from children. Store in a cool, well-ventilated place in approved containers that are tightly closed. Keep out of direct sunlight.

Suitable extinguishers

Alcohol-resistant foam, water spray mist. In the case of small fires, use water spray mist, foam or carbon dioxide.

ROLL FIRE is not suitable for heating rooms.

All that is left for us to do is to hope that you enjoy your ROLL FIRE and that it gives you lots of good times!

Please contact us if you have any questions or requests:

Conmoto J. Wagner GmbH & Co. KG | Schloss Möhler | Schlossallee 7 – 9
D - 33442 Herzebrock-Clarholz | Tel. +49 5245 92192-0 | Fax +49 5245 92192-22
www.conmoto.com | info@conmoto.com